

MOMENTS VESSEL LAVATORY FITTING

Installation Instructions 2506.15X



Certified to comply with ANSI A112.18.1M M968944 Rev. 1.3 (7/15)

Thank you for selecting American-Standard...the benchmark of fine quality for over 100 years.

To ensure that your installation proceeds smoothly--please read these instructions carefully before you begin.

Recommended Tools










INSTALL LAVATORY FAUCET


CAUTION Turn off hot and cold water supplies before beginning.

For single hole only.

NOTE; The FAUCET with EXTENSION is used for installation with above-counter sinks.


- With the collar of the EXTENSION (1) facing up, slide the EXTENSION (1) over the FAUCET SUPPLIES (2) and the MOUNTING STUD (3). The collar of the EXTENSION (1) fits into the groove of the faucet. Align the front flats on the faucet and extension.
- Seat SEAL (4) into groove in EXTENSION (1) base. Feed FAUCET SUPPLIES (2) and MOUNTING STUD (3) through mounting hole of deck.
- From below, push SUPORT PLATE (7), RETAINING WASHER and GASKET (5) onto MOUNTING STUD (3). Secure Faucet with MOUNTING NUT (6), pulling faucet to front of sink. Before final tightening, adjust faucet so that it is centered. Tighten MOUNTING NUT (6) to complete installation.





3 DRAIN INSTALLATION


- Apply a bead of PUTTY to underside of DRAIN BODY FLANGE (1).
- Feed DRAIN BODY (1) down through lavatory.
- Assembly GASKET (2) WASHER (3) and LOCKNUT (4) onto DRAIN BODY (1). Tighten LOCKNUT (4) firmly.
- Assembly TAILPIECE (5) to DRAIN BODY (1).



TEST INSTALLED FAUCET AND CHECK FOR LEAKS With HANDLE (1) in OFF position, turn on WATER SUPPLIES (2) and check all connections for leaks. Remove AERATOR (3). Remove AERATOR (1) to flush water lines thoroughly. Replace AERATOR (3).

5 SERVICE CAUTION Turn off hot and cold water supplies before beginning.

- Turn on valve and allow water supply temperatures to stabilize. Move HANDLE to full HOT setting. Check water temperature.
- To decrease hot limit temperature setting:
 - Pull out Plug Button (1), loosen Handle Set Screw (2) and remove Handle (3) from Cartridge Stem (5). Remove Cartridge Cover (4).
 - Lift Setting Insert (6), rotate counterclockwise one notch and replace. Check water temperature and repeat if necessary. Unit is factory set at "O" (full HOT water). As the setting number increases, the more cold water is supplied in the full HOT handle position.
 - Replace Cartridge Cover (4). Align Handle (3) and tighten Set Screw (2). Replace Plug Button (1).



CARE INSTRUCTIONS:

DO: SIMPLY RINSE THE PRODUCT CLEAN WITH CLEAR WATER. DRY WITH A SOFT COTTON FLANNEL CLOTH.

DO NOT: DO NOT CLEAN THE PRODUCT WITH SOAPS, ACID, POLISH, ABRASIVES, HARSH CLEANERS, OR A
CLOTH WITH A COARSE SURFACE.

M968944 Rev. 1.3 (7/15)

American Standard **MOMENTS VESSEL FITTING MODEL NUMBER** 2506.15X M962558-YYYOA Handle M962561-YYYOA CARTRIDGE COVER M923320-YYY0A CARTRIDGE NUT **A912740-0070A** O-RING **951970-0070A** CARTRIDGE Replace the "YYY" with appropriate finish code 002 **CHROME** M961619-0070A 075 MANIFOI D STAINLESS STEEL M964481-YYY0A AERATOR (1.2 GPM) M962562-YYYOA EXTENSION KIT **015025-YYY0A** DRAIN COMPLETE **A911836-0070A** SEAL A923480-0070A SUPPORT PLATE 070532-0040A TAILPIECE **M961714-0070A** MOUNTING KIT

HOT LINE FOR HELP

For toll-free information and answers to your questions, call: 1 (800) 442-1902

Mon. - Fri. 8:00 a.m. to 8:00 p.m. EST Saturday 10:00 a.m. to 4:00 p.m. EST

IN CANADA 1-800-387-0369 (TORONTO 1-905-306-1093) Weekdays 8:00 a.m. to 7:00 p.m. EST IN MEXICO 01-800-839-1200



M968944 Rev. 1.3 (7/15)