INSTALLATION INSTRUCTIONS

DXV ModulusTM **Pressure Balance Shower Valve Trim Kit**

Models D35120500 D35120500RB

To be used with D35000500.191 **Pressure Balanced Shower Valve**

Thank you for selecting DXV. To ensure that your installation proceeds smoothly, please read these instructions carefully before you begin.





Ш

S

Ш

 α

 $\mathbf{\alpha}$

0

Ш

⋖ S

RECOMMENDED TOOLS AND MATERIALS

Most of the procedures require the use of common tools and materials, which are available from hardware and plumbing supply stores. It is essential that the tools and materials be on hand before work has begun.








Flat Blade Screwdriver

TRIM DIMENSIONS:

For reference



In the United States:

One Centennial Avenue Piscataway, New Jersey 08855 Attention: Director of Customer Care

For residents of the United States, warranty information may also be obtained by calling the following toll free number: (800) 227-2734 www.DXV.com

In Canada:

DXV 5900 Avebury Road Mississauga, Ontario L5R 3M3 Canada

Toll Free: 1-800-387-0369 Local: 905-306-1093 Fax: 1-800-395-1498 www.DXV.ca

In Mexico:

DXV Via Morelos 330

Col. Santa Clara Coatitla Ecatepec, Estado de México 55540

Toll Free: 01-800-8391200 www.DXV.mx

1a INSTALL VALVE TRIM

CAUTION Turn off hot and cold water supplies before beginning.

- When finished tiling the wall, remove the PLASTER GUARD (1).
- Figure 1. Push CAP (2) over VALVE CARTRIDGE until seated against stop.


1b


• Figure 2. Mount ESCUTCHEON HOLDER (3) and gasket to valve body with SCREWS (4).

1c

• Figure 3. Install ESCUTCHEON (5) onto CAP (2) and push flush against finished wall. ESCUTCHEON (5) will snap fit onto ESCUTCHEON HOLDER (3).


Figure 3.





2 INSTALL HANDLE

- Install HANDLE ADAPTER (1) onto VALVE STEM (2) and secure with SCREW (3).
- Align LEVER HANDLE (4) so lever is facing down and tighten SET SCREW (5) with hex wrench to secure LEVER HANDLE (4). Install PLUG BUTTON (6).



TEST INSTALLED FAUCET

- Turn VALVE "off".
- With HANDLE in "off" position, turn on water supplies and check all connections for leaks.
- Operate HANDLE and flush water lines thoroughly.

