Ш

S


ш

 $\mathbf{\alpha}$ 

⋖


# **Randall® Wall Tub Spout** Model D35102760

Thank you for selecting DXV. To ensure that your installation proceeds smoothly, please read these instructions carefully before you begin.



#### **RECOMMENDED TOOLS AND MATERIALS**

Most of the procedures require the use of common tools and materials, which are available from hardware and plumbing supply stores. It is essential that the tools and materials be on hand before work is begun.




Phillips Screwdriver Plumbers' Putty or Caulking



Flat Blade Screwdriver

#### **ROUGHING-IN DIMENSIONS:**

• For reference



#### In the United States:

One Centennial Avenue Piscataway, New Jersey 08855 Attention: Director of Customer Care

For residents of the United States, warranty information may also be obtained by calling the following toll free number: (800) 227-2734 www.DXV.com

#### In Canada:

DXV 5900 Avebury Road Mississauga, Ontario L5R 3M3 Canada

Toll Free: 1-800-387-0369 Local: 905-306-1093 Fax: 1-800-395-1498 www.DXV.ca

#### In Mexico:


DXV Via Morelos 330 Col. Santa Clara Coatitla Ecatepec, Estado de México 55540

Toll Free: 01-800-8391200 www.DXV.mx

#### **REMOVE SPOUT ADAPTER**


#### **CAUTION: Protect finish on TUB SPOUT when installing.**

 To install TUB FILLER SPOUT (1) first remove SET SCREW (2) and pull SPOUT ADAPTER (3) from back of TUB FILLER SPOUT (1).




# 2 REMOVE PIPE CAP

 Remove PIPE CAP. Apply sealant to pipe nipple. With a 1/2" (12.7mm) hex wrench thread SPOUT ADAPTER (3) onto pipe nipple.




## 3 INSTALL SPOUT

- The SPOUT ADAPTER (3) should extend 1-1/8" (29 mm) from finished wall.
- Push TUB FILLER SPOUT (1) onto SPOUT ADAPTER (3) flush against finished wall.




### 4 SECURE SPOUT

 Align spout and tighten SET SCREW (2) to secure TUB FILLER SPOUT (1) to SPOUT ADAPTER (3).



SATIN BRASS



427