
## **Victorian**

### **Single Control Bar Faucet**



#### Model D35402400

Thank you for selecting DXV. To ensure that your installation proceeds smoothly, please read these instructions carefully before you begin.





#### **RECOMMENDED TOOLS AND MATERIALS**

Most of the procedures require the use of common tools and materials, which are available from hardware and plumbing supply stores. It is essential that the tools and materials be on hand before work has begun.










Adjustable Wrench

Plumbers' Putty or Caulking

Flat Blade Screwdriver

#### **ROUGHING-IN DIMENSIONS:**

• For reference



NOTE: Bore hole size is 1-3/8"

#### In the United States:

One Centennial Avenue Piscataway, New Jersey 08855 Attention: Director of Customer Care

For residents of the United States, warranty information may also be obtained by calling the following toll free number: (800) 227-2734 www.DXV.com

#### In Canada:

DXV 5900 Avebury Road Mississauga, Ontario L5R 3M3 Canada

Toll Free: 1-800-387-0369 Local: 905-306-1093 Fax: 1-800-395-1498 www.DXV.ca

#### In Mexico:

Via Morelos 330 Col. Santa Clara Coatitla Ecatepec, Estado de México 55540


Toll Free: 01-800-8391200 www.DXV.mx

S

#### 1 INSTALL FITTING

**CAUTION** Turn off hot and cold water supplies before beginning.

- Make certain the O-RING (2) is properly seated in recess of FAUCET BASE (3).
- Insert HOSE (9), SHANK (10) through center hole of sink or mounting surface.
- Assemble three BRASS SCREW (8) into the FIXATION RING (7).
- Assemble SUPPORT PLATE (5) METAL WASHER (6), and FIXATION RING (7) onto SHANK (10) from underside of sink. Hand tighten the FIXATION RING (7) and check that FAUCET (1) is centered.
- Use a screwdriver to tighten SCREW (8) on FIXATION RING (7). Work your way around FIXATION RING (7), tightening the screws slightly each time until all are snug to ensure even pressure.




#### MAKE WATER SUPPLY CONNECTIONS

- Turn off hot and cold water supplies before beginning.
- Connect FLEXIBLE SUPPLIES (1, 2) directly to wall supplies. Connection on fitting supplies are 3/8" compression. Connect left supply (Marked Red) to Hot and right supply (Marked Blue) to Cold wall supply. Use adjustable wrench to tighten connections. Do not over tighten. Faucet supplies are 21" long from faucet base.


Note: If additional supply length is required, installer must purchase additional parts separately.

Important: If SUPPLY HOSES (1, 2) are too long, loop as illustrated to avoid kinking.



#### 3 TEST INSTALLED FAUCET

- Move HANDLE (1) into "off" position.
- Turn on water supplies and check all connections for leaks.



#### TROUBLE SHOOTING

Low water flow from faucet:

• Remove AERATOR (2) and clean if necessary.



M965537 Rev. 1.2 (4/17)



# **Victorian**Single Control Bar Faucet

**MODEL NUMBER** 

D35402400

Replace the "YYY" with appropriate finish code

